

# Installation instructions

## AEROSANA® VISCONN FIBRE

### Application using brush or scraper



#### 1. Stir the product

Before application from the bucket: stir thoroughly.



#### 2. Clean the subsurface

Clean loose material and coarse dirt from the subsurface using a brush, for example.



#### 3. Determine the crack width

AEROSANA VISCONN FIBRE bridges cracks of up to 20 mm (3/4") in width.



#### 4. Painting over cracks up to 8 mm (5/16") in width

Cracks of up to a maximum of 8 mm (5/16") in width can be simply painted over.

When doing so, guide the brush flat across the crack so that the gap becomes completely filled.



#### 5. Filling cracks up to 20 mm (3/4") in width

For cracks of 8 - 20 mm (5/16" - 3/4") in width, apply AEROSANA VISCONN FIBRE deep into the crack.

To do so, the gap must be filled with sealant to a depth of at least half the width of the gap.

#### 6. Closing up holes

Holes of up to a maximum of 70 mm (2 3/4") in diameter at their widest point can be closed using AEROSANA FLEECE and AEROSANA VISCONN FIBRE.



### 7. Paint the subsurface

Apply AEROSANA VISCONN FIBRE with a thickness of at least 1 mm (40 mils) around the hole.



### 9. Paint over the fleece

Paint over the entire area of the bridging fleece with AEROSANA VISCONN FIBRE.



### 12. Determine the fleece strip length

Determining the strip length of AEROSANA FLEECE: the bridging fleece must be in contact with the masonry and the pipe to be bonded over at least 40 mm (1 5/8") for each.



### 8. Apply the fleece

Cut AEROSANA FLEECE to shape and apply this onto the liquid sealant. Avoid cavities. The bridging fleece must be in contact with the masonry over a width of at least 40 mm (1 5/8") around the hole.



### 11. Sealing around penetrations

When creating joints to penetrations, clean loose material and coarse dirt from the subsurface with a brush, for example.



### 13. Cut the fleece strip

Cut a strip of AEROSANA FLEECE in such a way that its width is slightly greater than half the pipe diameter. The strip can then be worked onto the pipe more easily.



#### 14. Paint the subsurface

Apply AEROSANA VISCONN FIBRE with a thickness of at least 1 mm (40 mils) around the hole and pipe.



#### 16. Paint over the fleece

Then apply AEROSANA VISCONN FIBRE to the fleece strips, the masonry and the pipe.



#### 18. Paint over the fleece

To finish, paint over the joint generously with AEROSANA VISCONN FIBRE.



#### 15. Apply the first fleece layer

Apply the fleece pieces onto the liquid AEROSANA VISCONN FIBRE. Ensure that the valleys formed are free of tension.



#### 17. Apply the second fleece layer

Apply additional fleece strips so that the gap is completely closed. Avoid hollows (valleys).



#### 20. Awkward detail features

AEROSANA VISCONN FIBRE can be used to achieve airtightness for geometrically challenging joints (e.g. on renovation projects) in a simple and reliable manner.



## 21. Paint the subsurface

Paint AEROSANA VISCONN FIBRE with a thickness of at least 1 mm (40 mils) onto the subsurfaces to be sealed.

In the case of changes of material or close to corners, the brush-on sealant must be applied onto at least 40 mm (1 5/8") of the subsurfaces.



## 23. Paint over the fleece

Paint the brush-on sealant onto AEROSANA FLEECE in the area around overlaps to ensure they stick to one another. Once all fleece pieces have been fitted, paint all of the joint with AEROSANA VISCONN FIBRE.



## 25. Colour change after drying

The colour changes to black during drying.

If gaps are noticed after application, these can be closed subsequently with AEROSANA VISCONN FIBRE.



## 22. Apply the first fleece layer

Cut pieces of AEROSANA FLEECE into shape and apply them onto the wet AEROSANA VISCONN FIBRE.



## 24. Protection against moisture

The drying time for the joint created is around 4 - 24 hours depending on the absorbency of the subsurfaces and the climate conditions. During this time, the joint must be protected against moisture.

## Eave refurbishment with AEROFIXX



### 1. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



### 2. Spray over birdsmouth joints

In the area around the birdsmouth joints, spray over the joints between rafters and the wallplate with a generous amount of sealant so that any movement of components that occurs can be accommodated.



### 3. Continue along the rest of the eave

Also apply a generous amount of AEROSANA VISCONN / FIBRE below the rafters in the area around the birdsmouth joints.



### 4. Seal wide joints

Switch the AIRFIXX to line application and completely fill the gap (in this case, between the wallplate and the knee wall) with AEROSANA VISCONN / FIBRE.



### 5. Spray over the joint

Set the AEROFIXX to spray application and spray over the joint in a generous manner. Apply the sealant to a width of at least 30 mm (1 1/4") on the surfaces to be sealed. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.

### 6. Use as a primer

If required, apply AEROSANA VISCONN /FIBRE as a primer onto timber that the refurbishment vapour control membrane (e.g. DASATOP) will be bonded to subsequently.



### 7. Stick the joint

After the sealant has fully dried, seal the refurbishment vapour control membrane in an airtight manner using TESCON VANA, for example.

## Joints at double collar ties with AEROFIXX



### 1. Initial situation



### 2. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



### 3. Check the joint width

Gaps of up to 3 mm can be filled using AEROSANA VISCONN. Use AEROSANA VISCONN FIBRE for wide gaps of up to 20 mm (3/4"). In this case, the gap must be filled with sealant to a depth of at least half the width of the gap.



### 4. Set the device

Set the AEROFIXX to line application.



### 5. Fill the joint

Fill the joint with a sufficient amount of AEROSANA VISCONN / FIBRE.



### 7. Work on detail features

Areas that are difficult to access can also be sealed conveniently using the spray method.



### 6. Spray over the joint

Set the AEROFIXX to spray application and spray over the joint in a generous manner.

Apply the sealant to a width of at least 30 mm (1 1/4") on the surfaces to be sealed. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.



### 8. Check the joint

If necessary, seal any gaps with a brush and AEROSANA VISCONN / FIBRE.



9. The finished joint at a double collar tie penetration

## Window joint with AEROFIXX



### 1. Initial situation

Window is installed, window joint has been filled with insulation material.



### 3. Cut away any excess insulation material

If necessary, cut away any protruding insulation.



### 2. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



### 4. Apply masking tape to the window frame

When doing this, leave a strip with a width of at least 6 mm free on the frame for subsequent sealing using AEROSANA VISCONN / FIBRE.

Alternatively, remove the joint insulation to a sufficient extent to create a clean surface for a lateral bond to the side of the window frame.



### 5. Spray on the sealant

Spray a sufficient amount of AEROSANA VISCONN / FIBRE onto the window frame, the joint insulation and the adjacent masonry. Apply the sealant evenly. Cracks and pores must be closed by flooding them. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.



### 7. Check the joint

If necessary, seal any gaps with a brush and AEROSANA VISCONN / FIBRE.



### 6. Continue around the rest of the window

Bond all four sides of the frame to the masonry using AEROSANA VISCONN / FIBRE.



### 8. Interior and exterior use

AEROSANA VISCONN / FIBRE can be used for interior and exterior window joints. The installation method is identical in both cases.



### 9. Remove the masking tape

Remove the protective masking tape immediately after the window joint is sealed.

Remove any traces of AEROSANA VISCONN / FIBRE from the window frame immediately using a damp cloth.

## Sealing wall-to-floor joints with AEROFIXX



### 1. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



### 2. Preparation of taped joints between boards, if required

If the gaps between adjacent wood-based panels have been taped using TESCON RAPIC to create airtight seals, this tape should be covered over with short lengths of TESCON VANA in the area close to the floor where a liquid sealant will be applied. The edges of the TESCON VANA must adhere directly onto the wood-based panel here.



### 3. Spray setting

Set the AEROFIXX to spray application.



### 4. Spray over the base joint

Spray the wall-to-floor joint area. Apply the sealant to a width of at least 30 mm (1 $\frac{3}{16}$ ") on the surfaces to be sealed.

The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.

## Substrates

Before application, check whether the subsurface is suitable for a liquid film. It may be necessary to apply a number of coats in the case of uneven or textured subsurfaces. Gaps (pieces broken out of the subsurface) or significant unevenness may need to be closed using AEROSANA FLEECE, taped over before application (e.g. with one of the CONTEGA SOLIDO adhesive tapes, depending on requirements) or levelled off with filler.

Subsurfaces should be cleaned.

Application temperature should be above +5 °C (+40 °F) subsurface and air temperature. There must be no water-repellent substances (e.g. grease or silicone) on components to be coated. Subsurfaces must be sufficiently dry and stable. Application is possible on moist, but not wet subsurfaces.

The liquid film adheres to all standard construction materials, e.g. mineral subsurfaces such as concrete and masonry (e.g. sand-lime bricks, other bricks, aerated concrete, pumice). Concrete or plaster subsurfaces may be sandy or crumbling to a small extent. Application is also possible to all pro clima membranes (SOLITEX ADHERO VISTO needs to be pre-treated with TESCON SPRIMER) and to membranes made of PE, PA, PP and aluminium, to unplanned, planed or painted wood, wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels), non-rusting metal subsurfaces and hard plastics (e.g. pipes, windows). AEROSANA VISCONN does not adhere to the TESCON RAPIC rapid-application adhesive tape. Cover TESCON RAPIC with a compatible adhesive tape (e.g. TESCON VANA) before applying liquid sealant.

Movement joints cannot be sealed due to the relative motion that can be expected. Transitions such as floor-wall joints are to be coated with the required minimum layer thickness (500 µm; 20 mils for wet application) along their entire lengths in the area to be sealed. Implement butt joints, such as valley areas for wood-fibre underlay panels, using AEROSANA FLEECE. If films (e.g. INTELLO) are to be sealed in an airtight manner, these should be stapled in place in the usual manner or else fixed in place using a suitable adhesive tape (e.g. TESCON VANA). The transition must be free of tension.

### Protect adjacent materials/surfaces

Materials/surfaces beside the areas to be coated should be protected; this applies particularly to visible surfaces such as wood, glass, ceramics, clinker bricks, natural stone, paint/varnish and metal. Wash away any splashes immediately with copious amounts of water. Do not wait until they have hardened. Clean tools with water immediately after use. Collect the water used for washing and dispose of it in accordance with the locally applicable regulations - e.g. European waste code: 080416.

## General conditions

Openings in the subsurface, e.g. cracks, may have a maximum width of 20 mm (3/4"). Cracks of up to a maximum of 8 mm (5/16") in width can be simply covered by applying sealant with a brush or spray gun.

For cracks of 8-20 mm (5/16"-3/4") in width, apply AEROSANA VISCONN FIBRE deep into the crack. To do so, the gap must be filled with sealant to a depth of at least half the width of the gap.

In the case of larger joint or crack widths, use AEROSANA FLEECE or an adhesive tape (e.g. TESCON VANA).

Alternatively, the opening can be filled using suitable plaster or mortar.

AEROSANA VISCONN FIBRE changes colour from blue to black when it dries. AEROSANA VISCONN FIBRE white does not change colour.

The film is to be protected against moisture (e.g. rain) during drying.

### Protective equipment

The air pressure raises airborne dust. For this reason, it is recommended that installers should wear personal protective equipment consisting of a mask, protective glasses and gloves, even in well-ventilated locations.

### AEROFIXX application

The AEROFIXX device is connected to a compressor with a suction flow rate of >300 l/min. The pressure should be set to 6 bar (87 psi). All AEROSANA VISCONN variants in 600 ml (20.3 US fl oz) foil cartridges can be applied using the AEROFIXX device. You can easily switch between line (bead) application and spray application by turning the spray head.

### Application with a brush

All AEROSANA VISCONN variants can be applied using a brush. To ensure efficient working, the width of the brush should be  $\geq$  50 mm (2"). Check the minimum layer thickness of 500  $\mu$ m (20 mils) using a measuring gauge.

### Storage

If this product has been in storage for a longer period, water (~5%) can be mixed into it to achieve a consistency that is suitable for spraying. Do not dilute the sealant material too much (risk of excessive flow and poor coverage of cracks). Closing the container in an airtight manner and covering it with a thin sheet will help to prevent drying out.

---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support] (<https://proclima.com/service/technical-support>).

---

### MOLL

#### bauökologische Produkte GmbH

Rheintalstraße 35 - 43  
D-68723 Schwetzingen  
Fon: +49 (0) 62 02 - 27 82.0  
eMail: [info@proclima.de](mailto:info@proclima.de)

For over 20 years, Ecological Building Systems has been at the forefront of environmental and sustainable building products supplying a range of innovative airtightness solutions and natural insulations backed up with expert technical support.

**As product suppliers in the UK and Ireland, we're happy to assist you with your projects and have expert technical and sales advice on hand.**



**Call us**

**Great Britain** +44 (0)1228 711511

**Ireland** +353 46 9432104



**Email us**

[info@ecologicalbuildingsystems.com](mailto:info@ecologicalbuildingsystems.com)



**Find us**

**Great Britain** Ecological Building Systems UK Ltd.,  
Cardewlees, Carlisle, Cumbria, CA5 6LF,  
United Kingdom

**Ireland** Ecological Building Systems Ltd.,  
Main Street, Athboy. Co. Meath, C15 Y678,  
Republic of Ireland