

# Installation instructions

## TESCON® Vana patch

### Installation steps



#### 1. Remove the release paper

The release paper can be easily removed from the adhesive tape using the finger lift.



#### 2. Stick in place

Position the patch in place with both hands.  
Ensure that the patch adheres to at least 2 cm of intact subsurface all around.  
Sealing must be carried out with no folds or creases.



#### 3. Rub to secure the adhesive bond

Carefully rub the TESCON VANA patch in place. The best results are achieved using the PRESSFIX application tool.

## Substrates

Clean subsurfaces before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, other vapour control and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other roof and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesive bonds are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels). Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels and smooth mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests may be necessary in certain cases. Pre-treatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

## General conditions

The adhesive bonds should not be subjected to tensile strain. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof sealing can only be achieved on vapour control membranes, roofing underlays or breather (WRB) membranes that have been laid without folds or creases. Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about application and construction is given in the pro clima planning documentation and application recommendations. If you have any questions, please call the pro clima technical hotline Ireland and UK:  
Phone: +353 46 9432104  
Fax: +353 46 9432435  
info@ecologicalbuildingsystems.com

---

**For Stockists contact****Ireland**

Phone: +353 (0)46 9432104  
Fax: +353 (0)46 9432435

**UK**

Phone: +44 (0)1228 711 511  
Fax: +44 (0)1228 712 280

**MOLL bauökologische Produkte GmbH**

Rheintalstraße 35 - 43  
68723 Schwetzingen  
Germany  
www.proclima.com

**Ecological Building Systems**

info@ecologicalbuildingsystems.com  
www.ecologicalbuildingsystems.com

For over 20 years, Ecological Building Systems has been at the forefront of environmental and sustainable building products supplying a range of innovative airtightness solutions and natural insulations backed up with expert technical support.

**As product suppliers in the UK and Ireland, we're happy to assist you with your projects and have expert technical and sales advice on hand.**



**Call us**

**Great Britain** +44 (0)1228 711511

**Ireland** +353 46 9432104



**Email us**

[info@ecologicalbuildingsystems.com](mailto:info@ecologicalbuildingsystems.com)



**Find us**

**Great Britain** Ecological Building Systems UK Ltd.,  
Cardewlees, Carlisle, Cumbria, CA5 6LF,  
United Kingdom

**Ireland** Ecological Building Systems Ltd.,  
Main Street, Athboy. Co. Meath, C15 Y678,  
Republic of Ireland