Installation instructions

ADHERO Floor Drain

Installation of the ADHERO Floor Drain



1. Preparation

Drill a hole with a diameter of at least 70 mm (2 3/4") through both the SOLITEX ADHERO and the structure underneath it.

Clean subsurfaces before taping. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on materials to be taped over. Subsurfaces must be sufficiently dry and stable. If necessary, remove any moisture with a wet-and-dry vacuum cleaner.

3. Connect drainage pipe

Connect the plastic pipe or temporary downpipe to the outlet of the floor drain and secure it to prevent it slipping off. Ensure the drainage water is piped out of the building reliably.



2. Installation

Insert the floor drain into the drillhole (if necessary, secure with countersunk screws) and tape it to the SOLITEX ADHERO with no folds or creases using TESCON VANA.

This adhesive tape should cover approx. 30 to 50 mm (12" to 20") of both the membrane and the ADHERO Floor Drain. Any water that is collected is to be drained from the building.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](https://proclima.com/service/technical-support).

MOLL

bauökologische Produkte GmbH

Rheintalstraße 35 - 43 D-68723 Schwetzingen Fon: +49 (0) 62 02 - 27 82.0 eMail: info@proclima.de



For over 20 years, Ecological Building Systems has been at the forefront of environmental and sustainable building products supplying a range of innovative airtightness solutions and natural insulations backed up with expert technical support.

As product suppliers in the UK and Ireland, we're happy to assist you with your projects and have expert technical and sales advice on hand.



Call us

Great Britain +44 (0)1228 711511 Ireland +353 46 9432104



Email us

info@ecologicalbuildingsystems.com



Find us

Great Britain Ecological Building Systems UK Ltd., Cardewlees, Carlisle, Cumbria, CA5 6LF, United Kingdom

Ireland Ecological Building Systems Ltd., Main Street, Athboy. Co. Meath, C15 Y678, Republic of Ireland

