

Solvent-free primer for interior and exterior use



Technical data

Material					
Main component	Acrylic copolymer, solvent-free				
Property	Regulation	Value			
Colour		White			
Installation temperature		-10 °C to 45 °C ; 14 °F to 113 °F			
Temperature resistance		Permanent -40 °C to 90 °C ; -40 °F to 194 °F			
Coverage		~ 4.5 m²/l			
Storage		Protect from frost, cool and dry			

Areas of application

For preparation and stabilisation of subsurfaces for subsequent application of pro clima adhesive tapes such as TESCON VANA, TESCON PROFECT and sealing tapes in the EXTOSEAL series. Suitable for wood, wood-fibre boards, masonry, roofs, walls and ground slabs.

Coverage

Delivery form	Content Applica	Coverage			
Tin	2.5	60 mm ~	ı ∼185 m; 200 yd		
		75 mm ~	150 m; 164 yd		
		150 mm	~75 m; 82 yd		
Dispenser bottle	· 1 l	60 mm	~75 m; 82 yd		
		75 mm	~60 m; 65 yd		
		150 mm	~30 m; 33 yd		

The quantity used may vary depending on the substrate and application method.

Supply forms

Art. no.	GTIN	Contents	Weight	Sales unit	Container
11449	4026639114495	1	1.13 kg	6	540
11430	4026639114303	2.5	3 kg	4	160

Advantages

- ✓ Secure bonds: penetrates deep and strengthens dusty subsurfaces or subsurfaces with insufficient stability
- ✓ Saves time: no drying time is necessary on absorbent subsurfaces
- ✓ More flexible work: use on dry and slightly moist subsurfaces
- \checkmark Can be applied and spread with just one hand using the application bottle
- ✓ Can be used at any time of the year: can also be applied during frosty conditions
- ✓ Excellent values in hazardous substance testing, has been tested according to the ISO 16000 evaluation scheme, solvent-free

Substrates

Before primer is applied, clean the subsurfaces. Frozen and soaked subsurfaces are not suitable for the application of primer. There must be no water-repellent substances (e.g. grease or silicone) on the subsurface.

All mineral surfaces (e.g. plaster or concrete) and (used) timber subsurfaces can be pre-treated. It is also possible to strengthen porous materials such as wood-fibre underlay panels.

Permeable absorbent subsurfaces (e.g. wood-fibre underlay panels) may be slightly moist. In this case, the adhesive tape to be used can be applied directly onto primer that is still wet. The product achieves its final level of strength only when it has dried. It may be advisable to use covers to protect the area that has been treated. Primer that has not yet fully dried must be protected against the effects of the weather. The amount of primer to be applied depends on the absorbency of the substrate; it is your responsibility to determine this.

If butyl rubber tapes (e.g. EXOSEAL range) that hinder diffusion are applied onto relatively well-sealed, non-absorbent subsurfaces (e.g. concrete), the primer must first be allowed to fully dry before the adhesive tape is put in place.

Only ORCON CLASSIC or ORCON MULTIBOND can be used when applying primer for adhesive sealants. The primer and ORCON CLASSIC must be fully dried (1-2 days) before the membrane material is stuck in place (dry process).

General conditions

Shake or stir the can well before use. One litre of primer can be used to treat an area of about 4.5 m² (48 ft²).



Datasheet TESCON PRIMER RP



*Information sur le niveau d'émission de substances volatiles dans l'air intérieur, présentant un risque de toxicité par inhalation, sur une échelle de classe allant de A+ (très faibles émissions) à C (fortes missions)





The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about application and construction is given in the pro clima planning documentation and application recommendations. If you have any questions, please call the pro clima technical hotline Ireland and

Phone: +353 46 9432104 Fax: +353 46 9432435

info@ecologicalbuildingsystems.com

For Stockists contact

Ireland

Phone: +353 (0)46 9432104 Fax: +353 (0)46 9432435

UK

Phone: +44 (0)1228 711 511 Fax: +44 (0)1228 712 280

Ecological Building Systems

info@ecologicalbuildingsystems.com www.ecologicalbuildingsystems.com

MOLL bauökologische Produkte GmbH

Rheintalstraße 35 - 43 68723 Schwetzingen Germany www.proclima.com



For over 20 years, Ecological Building Systems has been at the forefront of environmental and sustainable building products supplying a range of innovative airtightness solutions and natural insulations backed up with expert technical support.

As product suppliers in the UK and Ireland, we're happy to assist you with your projects and have expert technical and sales advice on hand.



Call us

Great Britain +44 (0)1228 711511 Ireland +353 46 9432104



Email us

info@ecologicalbuildingsystems.com



Find us

Great Britain Ecological Building Systems UK Ltd., Cardewlees, Carlisle, Cumbria, CA5 6LF, United Kingdom

Ireland Ecological Building Systems Ltd., Main Street, Athboy. Co. Meath, C15 Y678, Republic of Ireland

